PCE Instruments

PCE Americas Inc. 711 Commerce Way Suite 8 Jupiter FL-33458 USA From outside US: +1 Tel: (561) 320-9162 Fax: (561) 320-9176 info@pce-americas.com PCE Instruments UK Ltd. Units 12/13 Southpoint Business Park Ensign way Hampshire / Southampton United Kingdom, SO31 4RF From outside UK: +44 Tel: (0) 2380 98703 0 Fax: (0) 2380 98703 9 info@pce-instruments.com

www.pce-instruments.com/english www.pce-instruments.com

Manual Laser Shaft Alignment Tool PCE-TU 3



Version 1.0 Date of creation: 09.09.2015 Date of last change: 01.03.2016

Contents

1	Introduction	5
2	Safety notes	5
2.1	Precautions	5
3	Specifications	6
4	System description	7
4.1	Technical description	7
4.2 4.2.2	Application 1 CE-Conformity	8 8
4.3	Delivery content	8
4.4	Misalignment parameters	9
5	Machine alignment	.10
5.1	Determination of measurement data	. 10
5.2	System setup	. 11
5.3	Connection of the measurement sensors	. 11
5.4	Entering of the dimensions	. 12
5.5	Rough alignment	. 14
5.5.′	1 Rough alignment (var. 1)	. 14
6	Commissioning	.15
6.1	General control keys	. 15
62	Starting the PCE-TU 3	. 15
0.2	5	
0.2 7	Machine alignment	.16
7.1 7.1.2 7.1.2 7.1.2 7.1.2 7.1.4 7.1.4	Machine alignment Horizontal alignment 1 Enter dimensions 2 Change parameters 3 Data acquisition 4 Result 5 Live Alignment	. 16 . 17 . 18 . 19 . 23 . 24
7.1 7.1.7 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.2.2 7.2.2 7.2.2 7.2.2	Machine alignment Horizontal alignment 1 Enter dimensions 2 Change parameters 3 Data acquisition 4 Result 5 Live Alignment 1 Entry of machine alignment 2 Change/add parameters 3 Data acquisition	.16 .17 .18 .19 .23 .24 .28 .29 .30 .31 .36
7.1 7.1.2 7.1.2 7.1.2 7.1.2 7.1.4 7.1.4 7.2 7.2.2 7.2.2 7.2.2 7.2.4 7.2 7.2.4 7.3	Machine alignment Horizontal alignment 1 Enter dimensions 2 Change parameters 3 Data acquisition 4 Result 5 Live Alignment 1 Entry of machine alignment 2 Change/add parameters 3 Data acquisition 2 Soft Foot Measurement	.16 .17 .18 .19 .23 .24 .28 .29 .30 .31 .36 .40
7.1 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.2.2 7.	Machine alignment. Horizontal alignment. Enter dimensions Change parameters Data acquisition Result Live Alignment Vertical machine alignment Nation Entry of machine dimension Change/add parameters Data acquisition Result Change/add parameters Data acquisition Result Soft Foot Measurement Drive Shaft Alignment Set machine dimensions and measurement units Change parameters Collect data and align Proceed as in the horizontal machine alignment. Pay attention to the	.16 .17 .18 .19 .23 .24 .28 .29 .30 .31 .36 .40 .41 .42 .43 .44
7.1 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.1.2 7.2.5 7.2.2 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.2.5 7.5 7.5 7.5 7.5 7.5 7.5 7.5 7.5 7.5 7	Machine alignment Horizontal alignment 1 Enter dimensions 2 Change parameters 3 Data acquisition 4 Result 5 Live Alignment 6 Live Alignment 7 Vertical machine alignment 8 Change/add parameters 9 Data acquisition 2 Change/add parameters 3 Data acquisition 4 Result 5 Soft Foot Measurement 0 Drive Shaft Alignment 1 Set machine dimensions and measurement units 2 Change parameters 3 Collect data and align Proceed as in the horizontal machine alignment. Pay attention to the wing differences: Alignment of machine trains 1 Short explanation 2 Execution of a machine train alignment 3 View measurement results	.16 .17 .18 .19 .23 .24 .29 .30 .31 .36 .40 .41 .42 .43 .44 .44 .44 .44 .44

PCE Instruments

9 Sv	stem settings	85
8.4.3 8.4.4	Carry out measurement View and save results	83 84
8.4.2	Measurement process	82
o.4 8.4.1	Main screen of the program	82 82
8.4	Rectangularity program ("Squareness programm")	82
8.3.13	Live Mode	80
8.3.12	Tutorial for the use of splices	70 80
8.3.10 8.2.14	Carry out, access and replace measurement	/8
8.3.9	Rough alignment of the laser beam	77
8.3.8	Duration of the connection establishment	76
8.3.7	Carry out measurements	76
8.3.6	Configuration process	76
8.3.5	Splice explanation	75
8.3.4	Screen overview	75
8.3.3	Main screen of the program (configure positions and change parameters).	74
832	Carry out a straightness measurement	74 74
0.3 8 3 1	Sudividuess Floyian	14 71
0.2	Stroightnoop Drogram	74
8.2.8	Live Mode	73
0.2.0 827	View and save results	/ I 72
0.2.5 8.2.6	Duration of the connection establishment.	/U 71
8.2.4	Carry out measurement	70
8.2.3	Configuration process	69
8.2.2	Main screen of the program (configuration of planes and changing of parameters)	68
8.2.1	Short explanation	68
8.2	Bores and centre line programme	68
8.1.15	View statistics	66
8.1.14	Enter tolerances	66
8.1.13	Result modes	65
8.1.12	Define reference points	65
8.1.11	Reference modes	64
8 1 10	View and save results	62 64
8.1.8	Editing screen for circular grid	62
8.1.7	Editing screen for rectangular grid	61
8.1.6	Edit the grid	60
8.1.5	Create circular grid	60
8.1.4	Create or edit a rectangular grid	59
8.1.3	Change parameters	57
0.1.1 8.1.2	Short explanation	51 57
8.1	Flatness Program	57
8 EX		5/
0 Ev	tended alignment tools	04 57
7.7.8	View and save results	54 54
7.7.7	Duration of the connection establishment	53
7.7.6	Carry out measurements	53
7.7.5	Screen overview	52
7.7.4	Configuration process	52
1.1.Z 7.7.3	Main screep of the program	51 51
<i>1.1.</i> 1	Short explanation	50
1.1	Plumbline Program	50



9.1	Set date and time	86
9.2	Configure automatic turn-off	87
9.3	View/set up program licences	88
9.4	Set data transfer of the sensor	89
9.5	Set the user language	90
9.6	Set USB-mode	91
10 Han	dling of the Data Dialogue window	92
11 "My	Documents" option	94
11.1	Find/organize folders and files	94
11.2	Save a report as PDF file	95
12 App	endix	96
13 Disp	oosal	97
14 Con	tact	97
14.1	PCE Instruments UK	97
14.2	PCE Americas	97

1 Introduction

Thank you for purchasing a Shaft alignment tool from PCE Instruments.

With the help of a Shaft alignment tool, you can perform shaft alignment on machines and motors quickly and easily. For this purpose, the Shaft alignment tool possesses two special laser sensors, which are fixed to the particular shaft. The Shaft alignment tool directly displays the corresponding correction values for every machine base after a short measurement time. In addition to special programs for the alignment of machines and motors, you can perform further geometrical measurements with the PCE-TU 3.

2 Safety notes

Please read this manual carefully and completely before you use the device for the first time. The device may only be used by qualified personnel and repaired by PCE Instruments personnel. There is no warranty of damages or injuries caused by non-observance of the manual.

This manual is published from PCE Instruments without any guarantee.

We expressly point to our general guarantee terms, they can be found in our general terms of business.

If you have any questions please contact PCE Instruments.

2.1 Precautions

The PCE-TU 3 is a class II laser system with a typical wavelength of 670 nm, < 1MW capacity and a maximal radiation energy of 0,1 mJ per impulse. The class II laser meets the requirements according to ANSI, BS 4803, IEC 825 and the US American FDA. Note the following safety notes to avoid injury and damages on the device.

Caution:

- Do not ever directly look into the laser beam!
- Do not ever directly point the laser beam into anyone's eyes!

Warning!

Make sure that the machines you measure are not started by accident, because injuries might occur. To avoid that risk, you should either block the power switch in the OFF position or remove the corresponding fuses. These security measures need to be maintained until the measuring system is removed from the machines.

Disclaimer

Neither PCE Instruments, nor authorised salesmen can be blamed for damages on machines or working tools that might occur in the process of working with the PCE-TU 3 system. We check the manual carefully, to avoid possible errors. If you find an error in this manual, we would be very grateful, if you let us know.

3 Specifications

Sensor type	Position sensitive photodiodes	
Laser type	Visual, red 635 670 nm, < 1 MW	
Max. Distance	10 m between the sensors	
Measurement accuracy	± 1 % + 0,001	
Resolution	0,001 mm	
Display resolution	0,01 or 0,001 mm	
Inclinometer	Resolution 0,1 °	
Interface	USB, Bluetooth	
Memory	2 GB	
	Horizontal alignment in every position from 60 to	
	360°	
	Vertical alignment	
	Auto sweep mode	
Functions	Adjustable tolerances	
	Tilt measurement	
	Thermal growth	
	Spacer simulation	
	PDF reports	
Housing	With silicone protection	
	Protection type: IP65	
Power supply	NiMH-Battery (rechargeable)	
Environmental conditions	-10 +55 °C	
Weight	7.5 kg	

4 System description

4.1 Technical description



- 1 Lock button
- 2 Vertical alignment
- 3 Detector / target
- 4 Exit hole of the laser beam
- 5 Horizontal alignment

Front and top view of the measurement sensors



- 1 Reference point
- 2 Cable connector socket



Measurement sensor side view

1 Reference lines to measure the sensor distance

Top view of the measurement sensors



4.2 Application

The Shaft alignment tool PCE-TU 3 was designed to check and optimize the shaft alignment between machines. In order to do so, the relative position of two coupled machines (as for example a motor and a pump) need to be changed, in order to make sure, that the centre lines of the shaft need to be concentric during normal operation.

4.2.1 CE-Conformity

The Shaft alignment tool is conforming to the following CE requirements: 2006/95/EC, EN 61010-1:2001, EN 60825-1:2007, 2004/108/EC, EN 61326-1:2006, EN 61326-2-2:2006, EN 55011:2009+A1

4.3 Delivery content



1 x PCE-TU 3 display unit, 2 x probes, 2 x mounting sets for the probes, 1 x measurement tape , 1 x battery charger, 1 x connection cable, 1 x software, 1 x USB-cable, 1 x manual, 1 x carrying case



4.4 Misalignment parameters

Parallel misalignment
Angular misalignment
Parallel and angular misalignment (Offset + gap)

Parallel and angular misalignment can be determined in two rectangular planes. In order to eliminate parallel and angular misalignment, the position of the moveable machine (M) needs to be adjusted in both planes.

For horizontally mounted machines, the following needs to be applied: The position of the moveable machine (M) needs to be aligned in the horizontal and vertical plane.

For vertically mounted machines, the following needs to be applied:

You need to discuss the use of the movement of a moveable machine under perspectives of operation and efficiency with the machine operator. After that, you need to determine the arrangement of correction planes.

Stationary machines (S): The p

The position of the machine is not changed in the course of measurement and elimination of parallel and angular misalignment

Moveable machines (M): The position of the machine is adjusted, in order to eliminate parallel and angular misalignment

The measurement system determines the values for parallel and angular misalignment in the coupling (in two rectangular planes) and the corrective values which are necessary for the elimination of misalignments of the machine bases of the moveable machine (M). The following figure shows the misalignment and corrective values for the vertical plane.



Misalignment (vertical plane)

- 1 Parallel misalignment (Offset)
- 2 Angular misalignment
- 3 Corrective value
- S Stationary machine
- M Moveable machine



5 Machine alignment

- Mount the measurement sensors to the shaft of both machines, (S) and (M)
- Select the corresponding measurement program
- Enter the distance between sensor (S) and sensor (M) and between the coupling and the machine base.
- Press EXART, in order to collect measurements on three different positions of the shaft
- Adjust the position of the machine bases of the moveable machine according to the determined measurement results.

Caution!

For the implementation of the measurement, it is important to conform to the rotation direction of the shafts and to the relative position of the sensors to the machines (S) and (M).



The figure above, shows machine (S) from the point of view of machine (M) from 12 o'clock position. The surfaces of the measurement sensors are marked as S and M and should be mounted to the corresponding shaft of the machine.

5.1 Determination of measurement data

The Shaft alignment tool PCE-TU 3 is based on the measurement of a moving laser beam in the target window of the receiving sensor while the shaft, the sensor is mounted to, is rotated.

In order to determinate the axis alignment, at least three measurements (on different positions during the rotation of the shaft) need to be carried out. A rotation of about 180 ° is sufficient here.

If a rotation of 180 $^{\circ}$ should not be possible due to restricted spaces or an unfavourable arrangement of the machines, the PCE-TU 3 supports a mode for smaller rotation angles. Total rotations of 60 $^{\circ}$ are sufficient in this mode.

5.2 System setup

Before working with the Shaft alignment tool, you need to control the battery status, and recharge the battery, if necessary.

The battery status is displayed as a small, coloured figure on the bottom of the main menu of the instrument, while the exact battery status is available in the menu item "Setup".

Check and clean the surface of the laser detector and the exit hole of the sensor, if necessary.

Use a cotton pad soaked in alcohol for the cleaning. Do not use solvents for the cleaning under any circumstances.

Check date and time of the system clock and adjust them, if necessary.

5.3 Connection of the measurement sensors

There are serial ports on the display unit, as well as on the measurement sensors. The sensors need to be connected in series to the display unit with the enclosed cables. Refer to the following figure



Serial connection of the sensors

5.4 Entering of the dimensions

To achieve probable measurement results, you need to enter the distances between the sensors, the coupling and the machine bases first. The following figures show the required dimensions for both, horizontally and vertically mounted machines.



Horizontal alignment

- 1 Stationary machine
- 2 Sensor S
- 3 Sensor M
- 4 Moveable machine
- F1 Front machine base
- F2 Rear machine base
- **S-M** distance between the measurement sensors
- S-C distance between sensor S and the middle of the coupling
- S-F1 distance between sensor S and the machine base F1
- **S-F2** distance between sensor S and the machine base F2 (needs to be larger than S-F1). If the machine has three pairs of machine bases, the value can be adjusted after the measurement. After a new measurement, you receive the corrective values for the third pair of machine base.

PCE Instruments

Manual



Moveable machine

1 2 Stationary machine

S-M distance between the measurement sensors

distance between sensor S and the middle of the coupling distance between sensor S and the alignment plane F1 S-C

S-F1

5.5 Rough alignment

Rough alignment should only be applied, if the axis alignment of the machines is in such a bad condition, that the laser beams do not meet the detector during the rotation of the shaft anymore.

5.5.1 Rough alignment (var. 1)



View from Sensor S

- 1 Route of the laser beam during the rotation of the shaft
- 2 Laser beam outside the detector area.3 Fixing of the laser beam halfway of the

4

- Fixing of the laser beam halfway of the route to middle of the detector
- Alignment of the moveable machine (M), in order to make sure the laser beams meet (S) and (M) in the middle.
 - Rotate the shaft with the measurement sensors to the 9:00 position. Aim the middle of the closed detector opening.
 - Rotate the shaft with the measurement sensors to the 3 o'clock position.
 - Check, where the laser beams meet and use the adjustment screws to fix the laser beam in the middle of the route, to the middle of the detector (figure **view from sensor**).
 - Now align the moveable machine to the position, where the laser beam meets **S** and **M** from.
 - Continue with your regular measurement procedure.

6 Commissioning

6.1 General control keys

To close all active windows – except for the main menu –without saving, you can push the button (serves as ESC button).

The button serves to confirm or leave entering fields and active windows (except for windows with data entry, main screens of programs and some other).

6.2 Starting the PCE-TU 3

• Having completed the booting, the main menu appears on the display.



• To select a menu item, press

if the battery indication is flashing, you should immediately save all unsaved data and recharge the batteries. The symbol indicates that the instrument will turn off soon.

7 Machine alignment

7.1 Horizontal alignment

Mount the measurement sensor, **marked as S**, to the shaft of the stationary machine and the measurement sensor, **marked as M**, to the moveable machine. Connect the cable (**described in 3.3**) to the sensors and the main unit or configure the Bluetooth interface (only possible with the Bluetooth adaptor kit).

What should be noted in this window		Shortcuts in this window	
Firstly carry out the Soft Foot Measurement to avoid unexpected errors during the alignment check the result after alignment by measurement again		determination of new data	
Functions in this window		Continue alignment	
- Determine new data	3 DEF	Change machine dimensions and distances	
 Continue alignment Change of parameters Change machine dimensions and distances 	4 4 GHI	Change/add parameters	





7.1.1 Enter dimensions

What should be noted in this window		Shortcuts in this window	
		Navigate up	
Functions in this window		Navigate down	
 Enter distance sensor S – middle of the coupling Enter distance sensor S – sensor M Enter distance sensor S – middle of 	ENTER START	Save and leave and exit	
 Enter distance sensor S – front machine base Enter distance sensor S – rear machine base 		Confirm entry	
Measurement unit			

		Sensor S to middle of the coupling
-		
	S - F1 S - F2	Sensor S to Sensor M
S-C	48	
S-M	96	Sensor S to front
S-F1	110	machine base
S-F2	310	
Press 'S	TART' for save and exit;	Sensor S to rear machine base
"MENU"	tor exit	



7.1.2 Change parameters

Press 4 to change the parameters.

What should be noted in this window		Shortcuts in this window	
	Only use the "Biaxial Live" alignment function with stable shaft positions, because the smallest rotations can lead to errors	2▲ ABC	Activate/deactivate manual data entry
	Functions in this window	3 DEF	Activate/deactivate manual angle entry
		4 ◀ GHI	Use 2 or 3 decimal digits
-	Manual entry or use of the sensor data Manual angle entry or data from integrated inclinometer	5 JKL	Select between Inch and mm as measurement unit
-	Selection between 2 or 3 decimal digits	6 MNO	Activate/deactivate Biaxial Live alignment
-	Activate/deactivate "Biaxial Live"	9¢ wxyz	Entry for averaging
	alignment function	ENTER	Save and exit





7.1.3 Data acquisition

Push $1_{(i)}$ to collect data.

What should be noted in this window		Shortcuts in this window		
	Before starting a new alignment process, you need to enter dimensions and parameters			
	Do not change the position of measurement units when work is interrupted	0 DEL	Start again (deletes all values) Confirmation dialogue appears	
	Laser is now switched on			
Functio	ons in this window	1	Enter Ys-values, if manual entry is activated	
		2▲ ABC	Enter Ym-values, if manual entry is activated	
		4 ◀ GHI	Enter angle, if manual entry is activated	
		* *	If cursor is on the first place in the entry field, push this button twice to reverse sign	
-	Collect measured values (up to 36) Select between auto sweep and	6 MNO	Select the measurement unit (mm or inch)	
	manual mode	7 PQRS	Set parallel misalignment (Offset)	
-	Manual entry of Ys- and Ym-values (if activated)	8 ¢ TUV	Save all data in one file (see chapter 10 "Handling of the Data Dialogue window")	
-	Manual angle entry (if activated)	9 ¢ WXYZ	Load data from file (see chapter 10 " Handling of the Data Dialogue window ")	
-	Selection of measurement unit (mm/inch)	CLR I←	Delete currently selected reading	
-	Navigate through collected data	*	Enter new value. You have to switch to the last value saved, to make this option possible	
-	Restart (all values are deleted)	ENTER START	Save the current value or replace already saved values	
-	Set Offset	8	Navigate through data	
-	Save collected data	F5	Continue to the result window. All necessary conditions need to be fulfilled	
-	Load collected data	F2	Open popup menu	
Symbo	Is and status in this window	F4	Activate/deactivate auto-sweep. Auto- sweep can only be activated at the beginning of data acquisition or after restart. Manual entry of values and inclination need to be deactivated	
A blinking amber-coloured "C			display means that currently no data can be	
	received from the sensors	·		
[R]	A blinking red "R" in the di reading. This one can be d	splay mean deleted or re	ns that you are already viewing a stored eplaced. If this sign is not displayed in the	
window, the current value has not been saved yet			en saved yet. Pressing 🔤 🔤 , you can store	



	the value.
S	The absence of the laser beam position indicator and a red blinking frame of the position indicator mean, that no laser beam meets arrives or no sensor data are recognized.
9 3 6	An empty dial means that there is currently no angle established (or averaging is not completed) or that the rotation angle (to the next position) is too small (lower than 6°)
	A bright red indication means that the rotation angle does not meet the requirements of the single measurement points (at least 60°).
0	A yellow indictaion means that the rotation angle is over 60°.
	A green indication means that the rotation angle is over the recommended area (over 90°).
‡	This symbol means that an expanded Y-value range is used.
Ø	A crossed-out symbol means that the auto-sweep mode is deactivated.
E4	This symbol means that the auto-sweep mode is activated.



Description of the dial

Saved measurement points are marked as green sectors on the dial and coloured points next to them. The coloured points are round by default. If a coloured dot is square, it means that you are currently viewing this saved measurement point. The colour of the dot informs about the standard deviation of the current alignment function.

A blue dot means that the data are not ready (less than 3 measurement points are saved).
A green dot means that the data are good.
A yellow dot means that the data are not good, but acceptable.
A red dot means that the data are bad. This measurement needs to be deleted or replaced. If you use a small amount of measurement points it might occur, that other points but this point are bad. For this case, you should use more measurement points to find out which one is bad

Use the adjustment screws on the measurement sensors to align the laser beams one after the other to the middle of the detector opening (figure front and top view of the sensor/side view of the sensor). If the laser beams aim both detectors, open the covers. The X- & Y-coordinates and the position von **S** and **M** are now displayed on the monitor. Rotate the shaft into the selected 1^{st} measurement position. You can now switch to Auto-Sweep Mode or remain in the manual mode and save the active measurement point

by pressing . Save as many measurement points as possible (at least 3) and use a rotation angle as

large as possible (at least 60°). If you have collected the necessary data, press ^{F5} to start the alignment.

7.1.3.1 Set the parallel misalignment (offset)

Press Press, for Offset settings.

What should be noted in this window		Shortcuts in this window	
	Do not rotate the shaft, especially not while adjusting the sensors. Do not delete the parallel misalignment (offset), after it was saved. Otherwise, you have to repeat the whole data acquisition process.	1	Select the first setup phase
Functions in this window			Select the second setup phase
		0 DEL	Delete the first Offset value and to return to the first setup phase. Note: Do not perform this, if the settings are already complete.
			Save the set offset value.

Manual





The Offset setup is a process consisting of two steps. Start with the first phase. Three digits need to be accepted here. Having accepted these values, hit accepted to be second phase. Adjust the laser beam, until the value becomes 0 and wait for 5 seconds. Push to save the Offset value. After you have left the Offset menu, the symbol appears to display the Offset settings.



7.1.4 Result

To display the result of the measurement, push $[F_5]$, if you are located in the measurement screen or push [ABC], if you are located in the "horizontal alignment" option.

What should be noted in this window	Shortcuts in this window		
Do not rotate the shaft, while moving the machine. Do not change the position of the measurement unit, while Live Mode is activated	ODEL	Entry of misalignment tolerances	
Functions in this window	1	Spacer simulation	
		For flange correction view (just vertically)	
- View the calculated misalignment	3 DEF	Selection between 2 or 3 decimal digits	
 Carry out Live Alignment Pause/continue Live Mode Manual entry of the angle (if 	4 4 GHI	Manual entry of the angles (if activated). In this case, you need to interrupt the Live mode and enter the angle afterwards.	
activated) - Selection between 2 or 3 decimal	* *	If the cursor is in the first place of an entry field, push the button twice, to reverse sign	
digits - Selection of the measurement unit	5 V JKL	Entry of thermal growth	
(mm/inch)	6 MNO	Selection of the measurement unit (mm/mils)	
- Entry of tolerances	7 PQRS	Interrupt/continue Live Alignment	
 Save the alignment results Load the alignment results Spacer simulation 	8 * TUV	Save the alignment results to a file (see chapter 10 "Handling of the Data Dialogue window")	
	9 ¢ wxyz	Load results from file (see chapter 10 "Handling of the Data Dialogue window")	
Symbols	and status	in this screen	
	A yellow of the me averaging deactivate	A yellow dial in the alignment screen means that the angle of the measurement points is not accepted or that averaging is not completed. The Live Alignment mode is deactivated in this case.	
-	A red half misalignn misalignn in grey co	A red half of a coupling means that the current misalignment is out of the tolerance limits. If the misalignment is within these limits, the symbol is displayed in grey colour.	
	A blinking means the Otherwise	checkbox in the headline of the particular plane at Live Alignment can be used for this plane. e, this is not possible for the particular plane.	
Error - shafts turned!	This blink shaft was mode will pause it a	This blinking error report means that the position of the shaft was changed unexpectedly. The Live Alignment mode will be deactivated. To activate it again, press $\frac{7}{PORS}$ to pause it and then $\frac{7}{PORS}$ again to continue	



Manual



The corrective values for the machine bases F1 and F2 of the moveable machine (M) on the horizontal plane show the horizontal displacement. Positive values tell you, that the bases need to be pushed, where negative values show that bases need to be pulled.

The corrective values for the machine bases F1 and F2 of the moveable machine (M) on the vertical plane show the vertical displacement. Positive values express, that the machine bases need to be lifted, where negative values tell you that they need to be lowered.

7.1.5 Live Alignment

7.1.5.1 Horizontal Live Alignment

To start the horizontal Live Alignment mode, the sensors should be in the 9 or 3 o'clock position. If you

need to rotate the shaft, you have to pause the live mode by pressing ⁷_{pars}. Turn the shafts to the required

position now and continue the live alignment by pressing another time. Do not forget to enter the angle manually, if this option is activated. After a short message, Live Alignment should be enabled for the required plane (indicated by a blinking checkbox in the plane headline. Loosen the machine bases now and start the adjustment with the help of the calculated corrective values.

7.1.5.2 Vertical Live Alignment

To start the vertical Live Alignment mode, the sensors should be in the 6 o'clock or 12 o'clock position. If the shafts need to be rotated, you should proceed as described in the horizontal Live Alignment mode. Plane 6-12 should now be enabled for the Live Alignment. Loosen the machine bases and align them by means of the corrective values.

7.1.5.3 Biaxial (Y,X) Live Alignment

The biaxial Live Alignment process does almost take place as the horizontal or vertical alignment. The only difference is, that the sensors do not need to be in a predefined position. Nevertheless, it is recommended to place the sensors at an angle of about 45° (45°, 135°, 225°, 315°), to avoid measurement errors.

Movements of the shafts should be avoided in the course of biaxial alignment!

PCE Instruments

7.1.5.4 Carry on working after the position of the sensors has been changed

Before you continue with the alignment, after the position of the sensors has been changed, you need to place the sensors in two predefined positions (3/9 o'clock and 6/12 o'clock). A notification describing the procedure will appear. Do not forget to enter the angle manually, if this option is activated. If the sensors have been placed in a predefined position, the next step is automatically continued after a short setting

time. If the shafts are already set, the setting time can be skipped by pressing



After the first step is finished (e.g. 3:00 /9:00 position), the position indication changes with the note for the second step (e.g. 6:00/12:00 position).

After the second step is finished as well, the note and the yellow dial vanish and the Live Alignment process starts.

7.1.5.5 Entry of tolerances

To enter tolerances, press

Functions in this window	Shortcuts in this window	
	F2 Adjust tolerances via RPM (rotations per minute)	
	F3 Manual entry of tolerances	
 Selection of industry standard tolerances via the RPM selection 	If the RPM selection is activated: Raise RPM by one step. If manual entry is activated: Select parallel misalignment	
- Manual tolerance entry	 If RPM selection is activated: Reduce RPM by one step. If manual entry is activated: Select angular misalignment entry 	
	Save and exit	





7.1.5.6 Entry of thermal growth

To enter thermal growth, press

Functions in this window		Shortcuts in this window
		Navigate up through the entry fields
- Enter horizontal parallel misalignment extension		
- Enter horizontal angular misalignment extension		Navigate down through the entry fields
- Enter vertical parallel misalignment extension	* *	If the cursor is in the first place of an entry field, push the button twice, to reverse sign
- Enter vertical angular misalignment extension	ENTER	Save and exit

PCE Instruments	Manual
Horizontal parallel misalignment extension	Measure
Horizontal angular misalignment extension	S M Ho III O
Vertical parallel misalignment extension	S M Vo and O Va and O Measurement unit
Vertical angular misalignment extension	Gap Metric: / 100 mm '' at first to '-', 'Enter' to save TS:0 AS:0 Ym:0 Am:0°

7.1.5.7 Spacer simulation

To simulate spacers, push 1

Functions in this window		Shortcuts in this window	
- Entry of the thickness of the front machine base		Navigate up through the entry fields	
 Entry of the thickness of the rear machine base (F2) 		Navigate down through the entry fields	
- Remaining misalignment		Save and exit	

Manual





7.2 Vertical machine alignment

Mount the measurement sensor, marked as ${\bf S},$ to the shaft of the stationary machine and the measurement sensor marked as ${\bf M}$ to the moveable machine.

Note: Mark the 3, 6, 9 and 12 o'clock position on the machine housing.

Connect the cable as described in chapter 5.3 "**Connection of the measurement sensors**" or configure the Bluetooth-interface (only with optional Bluetooth adaptor).

What should be noticed in this window	Shortcuts in this window	
Check the result after the alignment, by measurement again	1 Determine new data	
Functions in this window	Continue alignment process	
 Determine new data and start the alignment Continue the alignment 	Change the machine dimensions and distances	
Change parameters Change dimensions and distances	4 Add/change parameters	
- View/change		





7.2.1 Entry of machine dimension

To enter the machine dimensions, press 3

What should be noticed in this window		Shortcuts in this window	
$\begin{array}{ c c c } \hline & for correct \\ must be re \\ S-C \leq S-F \end{array}$	measurement results, the following spected: 1 < S-F2	\bigcirc	Navigate up through the entry fields
Fur	nctions in this window		Navigate down through the entry fields
- Enter dista coupling	nce sensor S – middle of the	8	Set the amount of bolts
- Enter dista	nce sensor S – sensor M		Save and exit
 Enter dista 	nce sensor S – edge of the machine		



7.2.2 Change/add parameters

What should be noticed in this window		Shortcuts in this window	
	Use the Biaxial Live function with stable shaft positions, because the smallest rotations can lead to errors	2▲ ABC	Activate/deactivate manual data entry
	Functions in this screen	4 ◀ GHI	Selection between 2 or 3 decimal digits
-	Manual entry or use of the sensor data	5 JKL	Selection of the measurement unit (mm/inch)
-	Selection between 2 or 3 decimal digits	6 MNO	Activate/deactivate Biaxial Live Alignment
-	Selection of the measurement unit (mm/inch)		
-	Alignment to the X- and Y-coordinates simultaneously or just to the Y-coordinates (default)	ENTER	Save and exit

Manual





7.2.3 Data acquisition

To collect data, press 10.

What should be noted in this window		Shortcuts in this window		
	Before starting a new alignment process, you need to enter dimensions and parameters			
	Do not change the position of measurement units when work is interrupted	0 DEL	Start again (deletes all values) Confirmation dialogue appears	
	Laser is now switched on			
Functio	ons in this window	1	Enter Ys-values, if manual entry is activated	
-	Collect measured values (up to 36)	2▲ ABC	Enter Ym-values, if manual entry is activated	
-	Select between auto sweep and manual mode	4 4 GHI	Enter angle/inclination, if manual entry is activated	
-	Manual entry of Ys- and Ym-values (if activated)	* *	If cursor is on the first place in the entry field, push this button twice to reverse sign	
-	Manual angle/inclination entry (if	6 MNO	Select the measurement unit (mm or inch)	
-	Selection of measurement unit	7 PQRS	Set parallel misalignment (Offset)	
	(mm/inch)	8 & TUV	Save all data in one file (see chapter 10 "Handling of the Data Dialogue window")	
-	Navigate through collected data	9 ¢ WXYZ	Load data from file (see chapter 10 " Handling of the Data Dialogue window ")	
-	Restart (all values are deleted)		Delete currently selected reading	
-	Set Offset	*	Enter new value. You have to switch to the last value saved, to make this option	



			possible
- Save collected data			Save the current value or replace already
		ENTER	save the current value of replace alleady
		START	(confirmation dialogue appears)
- Luau collecte	u uala		
			Navigate through data
		F5	Continue to the result window. All necessary conditions need to be fulfilled
		F2	Open popup menu
		F4	Activate/deactivate auto-sweep. Auto- sweep can only be activated at the beginning of data acquisition or after restart. Manual entry of values and inclination need to be deactivated
Symbols and status in	n this window		
[C]	A blinking amber-coloured	l "C" in the o	display means that currently no data can be
	received from the sensors	•	
[R]	A blinking red "R" in the display means that you are already viewing a stored reading. This one can be deleted or replaced. If this sign is not displayed in the window, the current value has not been saved yet. Pressing START , you can store the value.		
S	The absence of the laser beam position indicator and a red blinking frame of the position indicator mean, that no laser beam meets or no sensor data are recognized.		
9 3 6	An empty dial means that there is currently no angle established (or averaging is not completed) or that the rotation angle (to the next position) is too small (lower than 6°)		
	A bright red indication means that the rotation angle does not meet the requirements of the single measurement points (at least 60°).		
0	A yellow indictaion means that the rotation angle is over 60°.		
	A green indication means that the rotation angle is over the recommended area (over 90°).		
‡	This symbol means that an expanded Y-value range is used.		
F	A crossed-out symbol means that the auto-sweep mode is deactivated.		



Manual



Description of the dial

Saved measurement points are marked as green sectors on the dial and coloured points next to them. The coloured points are round by default. If a coloured dot is square, it means that you are currently viewing this saved measurement point. The colour of the dot informs about the standard deviation of the current alignment function.

•	A blue dot means that the data are not ready (less than 3 measurement points are saved).
•	A green dot means that the data are good.
•	A yellow dot means that the data are not good, but acceptable.
•	A red dot means that the data are bad. This measurement needs to be deleted or replaced. If you use a small amount of measurement points it might occur, that other points but this point are bad. For this case, you should use more
	measurement points to find out which one is bad.

Use the adjustment screws on the measurement sensors to align the laser beams one after the other to the middle of the detector opening (figure front and top view of the sensor/side view of the sensor). If the laser beams aim both detectors, open the covers. The X- & Y-coordinates and the position von **S** and **M** are now displayed on the monitor. Rotate the shaft into the selected 1st measurement position. Save

the active measurement point by pressing **STAFT**. Save as many measurement points as possible (at least 3) and use a rotation angle as large as possible (at least 60°). If you have collected the necessary data,

press ^{F5} to start the alignment.

7.2.3.1 Set the parallel misalignment (offset)

Press Press, for Offset settings.

What should be noted in this window		Shortcuts in this window	
	Do not rotate the shaft; especially not while adjusting the sensors. Do not delete the parallel misalignment (offset), after it was saved. Otherwise, you have to repeat the whole data acquisition process.	1	Select the first setup phase
Functions in this window		2▲ ABC	Select the second setup phase
		0 DEL	Delete the first Offset value and to return to the first setup phase. Note: Do not perform this, if the settings are already complete.
			Save the set offset value.

PCE Instruments

Manual



The Offset setup is a process consisting of two steps. Start with the first phase. Three digits need to be accepted here. Having accepted these values, push to get to the second phase. Adjust the laser beam, until the value gets 0 and wait for 5 seconds. Push to save the Offset value. After you have left the Offset menu, the symbol appears to display the Offset settings.

7.2.4 Result

To display the result of the measurement, push $[F_5]$, if you are located in the measurement screen or push [ABC], if you are located in the "horizontal alignment" option.

What should be noted in this window	Shortcuts in this window			
Do not rotate the shaft, while moving the machine. Do not change the position of the measurement unit, while Live Mode is activated	Entry of misalignment tolerances			
Functions in this window	1 Spacer simulation			
	For flange correction view (just vertically)			
- View the calculated misalignment	3 Selection between 2 or 3 decimal digits			
 Carry out Live Alignment Pause/continue Live Mode Manual entry of the angle (if 	Manual entry of the angles (if activated). In this case, you need to pause the Live mode and enter the angle afterwards.			
activated) - Selection between 2 or 3 decimal	If the cursor is in the first place of an entry field, push the button twice, to reverse sign			
- Selection of the measurement unit	5 Entry of thermal growth			
(mm/inch)	Selection of the measurement unit (mm/mils)			
- Entry of tolerances	Pause/continue Live Alignment			
 flanged bolt (with live update) Save the alignment results Load the alignment results 	Save the alignment results to a file (see chapter 10 "Handling of the Data Dialogue window")			
	Load results from file (see chapter 10 "Handling of the Data Dialogue window")			
Symbols and status in this screen				
	A yellow dial in the alignment screen means that the angle of the measurement points is not accepted or that averaging is not completed. The Live Alignment mode is deactivated in this case.			
4	A red half of a coupling means that the current misalignment is out of the tolerance limits. If the misalignment is within these limits, the symbol is displayed in grey colour.			
	A blinking checkbox in the headline of the particular plane means that Live Alignment can be used for this plane. Otherwise, this is not possible for the particular plane.			
Error - shafts turned!	This blinking error report means that the position of the shaft was changed unexpectedly. The Live Alignment mode will be deactivated. To activate it again, press to pause it and then reactivate again to continue.			


To eliminate angular misalignment, you need to correct the angle of the rotation axis of the moveable machine with the help of spacers with the values from the bolt corrective value window.

Do not change the lateral position of the moveable machine when adjusting the spacers.

9-3 plane Live Alignment

To start the 9-3 plane Live Alignment, the sensors should be located in the 9 or 3 o'clock position. If you

need to rotate the shafts, pause the Live Alignment and continue it by pressing been. Do not forget to enter the angle manually. After a short notification, the Live Alignment should be enabled for the required plane. (indicated by a blinking checkbox in the headline of the plane). Loosen the machine bases and start the adjustment with the help of the calculated corrective values in the 9-3 plane.

6-12 plane Live Alignment

To start the 6-12 plane Live Alignment, the sensors should be located in the 6 or 12 o'clock position If you need to rotate the shafts, proceed as described in the "9-3 plane Live Alignment". The 6-12 plane should be enabled for the Live Alignment now. Loosen the machine bases now and align the moveable machine in the 6-12 plane.

Biaxial Live Alignment

The biaxial Live Alignment process does almost take place as the horizontal or vertical alignment. The only difference is that the sensors do not need to be in a predefined position. Nevertheless, it is recommended to place the sensors at an angle of about 45° (45°, 135°, 225°, 315°), to avoid measurement errors.

7.2.4.1 View bolt corrective values

To view the corrective values for each bolt, press $2 \\ \frac{2}{ABC}$ to make the according window appear. To close the window, press $2 \\ \frac{2}{ABC}$ once again.



Before you continue working, after the position of the sensors was changed, you need to place the sensors in two predefined positions. Proceed as described in **7.1.5.4**. (" Carry on working after the position of the sensors has been changed")



7.2.4.2 Entry of tolerances

To enter tolerances, press

Functions in this window	Shortcuts in this window
	F2 Adjust tolerances via RPM (rotations per minute)
	F3 Manual entry of tolerances
 Selection of industry standard tolerances via the RPM selection 	 If the RPM selection is activated: Raise RPM by one step. If manual entry is activated: Select parallel misalignment
- Manual tolerance entry	If RPM selection is activated: Reduce RPM by one step. If manual entry is activated: Select angular misalignment entry
	[← Save and exit



7.3 Soft Foot Measurement

What should be noted in this window			Shortcuts in this window
	The machine dimensions should be entered first (go to the according menu item)	ENTER START	Start the Soft Foot Measurement. Rotate the sensors to the 12 o'clock position and adjust the laser until it aims the target plate S and M in the middle.
Functions in this window			Restart the Soft Foot Measurement
-	Perform Soft Foot Measurements for all machine feet	8 ¢ TUV	Save results to a file (see chapter 10 "Handling of the Data Dialogue window")

Firstly enter the machine dimensions (just as described with the horizontal alignment) or skip the process by pressing and go to the sensor aiming screen.





If the laser beams are aligned and you leave the sensor aiming screen, you get to the Soft Foot Measurement screen.

Now go through the following steps for every single machine base:

Loosen the mounting (placed on the red square) of the required machine base, wait for 5 seconds and press to store the value. Having done that, you need to remount the machine base and press **STAR**, to continue with the next base.

PCE Instruments

Manual





If all measurements are finished, a blinking symbol appears and you can save the measurement results by pressing this symbol. To restart the Soft Foot Measurement, press

7.4 Drive Shaft Alignment

This program serves to the alignment of those machines connected by a drive shaft or cardan shaft. With the optional mounting kit for cardan shafts, the sensors can be mounted. The cardan shaft alignment is mostly identical to the horizontal machine alignment. Therefore, please do refer to **chapters 7.1** ("Horizontal machine alignment") and 5.5 ("Rough alignment"). The differences to these chapters are described in the following

What should be noted in this window Shortcuts in this window Before the measurement, a Soft Foot Measurement should be carried out 1 to avoid unexpected measurement errors. **1** Acquire new data Check the result after alignment by measurement again 2 ▲ ABC Functions in this window Continue the alignment procedure Acquire new data and start alignment -Change the machine dimensions and 3 DEF Continue alignment distances Change distances and dimensions 4 ◀ GHI Change the paramters Change the parameters

Drive Shaft main menu





7.4.1 Set machine dimensions and measurement units

To set the machine dimensions and measurement units, press $\begin{bmatrix} 3 \\ DEF \end{bmatrix}$.

Functions in this window	Shortcuts in this window	
- Enter distance sensor S – sensor M	Navigate up	
	Navigate down	
 Enter distance front machine base –rear machine base 	F3 Switch between measurement units (mm/mils)	
	Save and exit	





7.4.2 Change parameters

Press 4, to change parameters.

W	hat should be noted in this window		Shortcuts in this window
	Only use the Biaxial Live function with stable shaft positions, because even the smallest rotations can lead to measurement errors	2 ABC	Activate/deactivate manual data entry
	Functions in this window	3 DEF	Activate/deactivate manual angle entry
		4 ◀ GHI	Select 2 or 3 decimal digits
-	Manual entry or use of the sensor data		
-	Manual angle entry	(5▼ JKL	Select mm or inch as measurement unit
-	Selection between 2 or 3 decimal digits	6 MNO	Activate/deactivate Biaxial Live Alignment
-	Selection between inch and mm as measurement unit Activate/deactivate Biaxial Live Alignment		Entry for averaging
			Save and exit



7.4.3 Collect data and align Proceed as in the horizontal machine alignment. Pay attention to the following differences:

- The minimal shaft rotation angle must not be smaller than 75°
- Corrective values for the parallel misalignment are irrelevant when it comes to cardan shafts and will not be displayed
- Standard tolerances cannot be used for cardan shafts. Please ignore them.
- Only corrective values for one machine base are needed, because parallel misalignment is not corrected with cardan shafts.

7.5 Alignment of machine trains

7.5.1 Short explanation

A machine train consists of three or more units with rotating shafts, which are connected with couplings, as for example driving unit – gear – driven unit. With a common alignment measurement, an alignment measurement for every single machine would be necessary. The PCE-TU 3 system performs all necessary measurements automatically and offers the possibility to define the stationary or reference machine. To use this function, you should be familiar to **chapter 7.1 ("Horizontal machine alignment"**).

7.5.2 Execution of a machine train alignment

To start the program, select "machine train" and press start. The main screen of the program will appear.

	What should be noted in this window	SI	Shortcuts in this window		
	Similar to the horizontal alignment, a Soft Foot Measurement should be carried out before. If needed, corrections should be made. Do not forget to enter the dimensions in the menu for the horizontal machine alignment.	0 DEL	Create a new train (initially 3		
	All needed dimensions should be entered correctly.				
	The Sensor M must always be placed right to the coupling on the machine; also it is actually a stationary one.				
	Functions in this window	1	Dimensions of the machines and the selected coupling need to be entered first.		
-	Create/modify/view a train		Collect data (refer to chapter 7.1 "Horizontal machine alignment") Use ^{F5} in the measurement screen to finish the collection process and return to the main		
-	Determine parameters	3	menu of the program		
-	Enter dimensions	DEF 4 4 GHI	Add a machine on the left side of the train		
-	View the measured data	5 JKL	Add a machine on the right side of the train		
			Set parameters		
-	Save the results	7 PQRS	reserved (no function)		
-	Load saved results	8 & TUV	Save results to a file (see chapter 10 "Handling of the Data Dialogue window")		
		9 ¢ wxyz	Load data from file (see chapter 10 "Handling of the Data		



				Dialogue window")		
	F2			Open pop-up menu		
		F3		Scroll left		
		F4		Scroll right		
		MENU		Exit program		
Symbols and status	in this	s wir	ndow			
A green checkbox near the middle entered correctly and that the data	of the coupling means that the dimensions were a were detected correctly					

Press [1] or [1], to scroll through the complete train; press [1], to enter the dimensions for the machine

of the current coupling. Press 6, to change the parameters (see chapter 7.1.2 "**Change parameters**"). press 2,

to determine misalignment for the current coupling. Every coupling is measured as described in **chapter 6.3** ("Soft Foot Measurement").

The minimal rotation angle of two adjacent measurement points is 18° and the minimal overall rotation angle is 75°. Press $\frac{3}{\text{DEF}}$ to view the measurement results.





7.5.3 View measurement results

To view the measurement results, press $\frac{3}{\text{DEF}}$ in the main menu screen of the program.

Functions in this window	Shortcuts in this window			
		Set tolerances for the current coupling. Note: The entered tolerances are always valid for the left shaft or machine.		
 Overview of measurement results and Soft Foot 		Set thermal growth. Note: The values for the thermal growth are always valid for the left shaft or machine.		
Measurement corrective	3 DEF	Zoom-in		
values	4 ◀ GHI	Zoom-out		
- Entry of shaft tolerances	5 JKL	Define the current machine as reference machine.		
Entry of thermal growthSave the results	8 & TUV	Save results to a file (see chapter 10 "Handling of the Data Dialogue window")		
	F2	Open pop-up menu		
	F3	Scroll left		
	F4	Scroll right		
	MENU	Exit program		
	Symbols and status in this window			
	If a red square appears on the machine place, it means that the entered dimensions or the evaluated data are not valid (or no data were acquired):			
	A magenta coloured shaft marks the stationary machine (reference machine).			



Manual





7.6 Spindle Program

To align spindles (for example of lathes), mount the transmitter (Sensor S by default) to the chuck and the receiver to the tool slide.

To start the Spindle Program, select "Spindle" in the main menu and press the main screen of the Spindle Program will appear.

7.6.1 Main screen of the Spindle Program

	What should be noted in this window		Shortcuts in this window	
^	The needed dimensions should be entered		Start new measurement or	
	correctly (can be changed later on, if	0 DEL	restart measurement (all	
]	recommended).		acquired data will be lost)	
	Functions in this window	1	Enter the amount of	
	Functions in this window		measurement points (positions)	
-	Enter dimensions		Enter the distance between the	
		*	measurement points (near and	
-	Start measurement		far)	
-	View measurement results (available, if all needed		Save results to a file (see	
	measurements are finished)	8 ⊗ TUV	chapter 10 "Handling of the	
			Data Dialogue window")	
-	Save			

7.6.2 Measurement process

Mark two points on the machine bed (near and far), where the receiver shall be placed on the tool slide for future measurement.

Enter the distance between the near and the far measurement point. Mount the transmitter to the spindle

and the receiver to the tool slide. You can carry out a rough alignment, if needed. Press (), to get to the measurement screen.

7.6.3 Carry out measurement

Press , to carry out a measurement. Use < and

, to switch between the measurement points.

Press , to return to the former screen





7.6.4 View and save results

The results of the misalignment of a spindle are available; after all four measurements were carried out. To leave the current screen, press were. To leave the Spindle Program, press again. To save the results, press were, refer to chapter 10 ("Handling of the Data Dialogue window")



7.7 Plumbline Program

7.7.1 Short explanation

The Plumbline Program is used to carry out straightness measurements on shafts and to measure their central axis relative to the plumbline. This program provides a function for self-calibration of the lasers, if they are fixed to the 180° position. The laser transmitter is placed on four sides of the shaft in the 12 and 6 o'clock position.

To achieve results which are as accurate as possible, you should carry out alignment very carefully (due to planes).



Plan your measurement placing the transmitter in the first position (12 o'clock) and confirm the position by manually entering the angle (just numbers, no "°"). Mark the measurement points on the shaft. Save all measurement results for the transmitter position. Move the transmitter to the opposite site of the shaft (6

o'clock position) and switch to the opposite side by pressing^{F3}. Confirm the new position by manually entering the angle (once per side) and save all readings for the new transmitter position.

7.7.2 Carry out Plumbline Measurement

To start the program, select "Plumbline" in the main menu of the instrument and press streen. The main screen of the program will appear.

7.7.3 Main screen of the program

	What should be noted in this window	Shortcuts in this window		
	The required dimensions should be entered correctly (can be changed later on, if recommended). The manual angle entry should always be used for vertical shafts	0 DEL	Start a new measurement	
	Functions in this window	1	Enter amount of measurement points (positions)	
			Activate/deactivate to equate all distances	
-	Create/modify/view points	*	Enter current distance	
-	Change parameters	5▼ JKL	Change parameters Note: The inclinator cannot be	
-	Enter dimensions		used for vertical measurements	
-	Start measurement	7 PQRS	required measurements are finished)	
-	View results (available, if all required measurements are finished)	8 ¢ TUV	Save results to a file (see chapter 10 "Handling of the Data Dialogue window")	
-	Save	9 ¢ wxyz	Load saved results from a file (see chapter 10 "Handling of the Data Dialogue window")	
-	Load		Select a point to enter the distance	

7.7.4 Configuration process

Enter the amount of measurement points (positions) by pressing $\begin{bmatrix} 1 \\ 0 \end{bmatrix}$ and then enter a value (between 2 and 300). If the measurement points are arranged in the same distance to one and another, press and make sure that the checkbox for "same distance" is activated. Press and enter the distance. If the points are arranged in different distances to each other, use and \mathbf{x} , to select the required point and press \mathbf{x} , to enter the distance to the next point. Repeat the process, until all distances are entered.

To change parameters, press 5×10^{10} . The parameter screen will appear.

To activate or deactivate the manual data entry, press

To activate or deactivate the manual angle entry, press

To switch between measurement units, press

To perform averaging, press with the sample number and confirm by pressing

To save and exit the parameter screen, press

7.7.5 Screen overview





7.7.6 Carry out measurements

Press in the main screen of the program, to make the measurement screen appear.

	What should be noted in this window	Shortcuts in this window		
	Align the transmitter very carefully with the help of a spirit plane, to receive a result as accurate as possible.	F3	Switch to the opposite site (12 or 6 o'clock position)	
	Functions in this window	1	Manually entering of the receiver value (V)	
		2 ABC	Manually entering of the receiver value (H)	
		4 ◀ GHI	Manually entering of the angle (necessary for the position confirmation)	
-	Carry out measurement	6 MNO	Switch between measurement units	
-	Manually entering data (if activated)	F2	Open context menu	
		ENTER START	Carry out or replace measurement	
			Move through measurement points	

7.7.7 Duration of the connection establishment

Depending on which interface is used to connect the sensors (Bluetooth or serial), the connection establishment can take between 2 and 30-40 seconds. It is recommended to wait about 10 seconds (cable connection) or about 50 seconds (wireless connection). If no connection is established after that time, check the sensors and the system settings of the PCE-TU 3.





 \bigcirc and \bigtriangledown , to switch between the measurement points (positions). Always pay attention to the current selected side of the shaft and switch it (if recommended) by pressing [13].

7.7.9 View and save results

If the measurements for all measurement points are finished, press *to display a result*. There are two

reference line models you can chose between by pressing Ref.point Mode: if one of the reference points is undefined, the result is the unchanged receiver value. If two reference points are defined, the result is the difference between the calculated reference line and the receiver value.

To define reference points, press i and enter reference point number 1 and reference point number 2. Press i to confirm. In order to delete a reference point, enter i as the value.

Best- Fit Mode: in this mode, the result is the difference between the calculated best fit reference line and the receiver value.

The result can be displayed as a table or a graph. Due to $\frac{2}{2}$, you can switch between these illustrations.



To save the result, press, (refer to chapter 10 "Handling of the Data Dialogue window")

To return to the main menu of the program, press

Functions in this window	Shortcuts in this window			
	Switch between table and graph illustration			
- Carry out measurement	Define reference point (use to confirm your entry			
Carry our measurement	5 Switch reference point mode			
- Manual data entry (if activated)	8.¢ TUV Save			
	7 PQRSRepeat measurement (all current data will be deleted)			
	ENTER START Return to measurement screen			





Ref. Po	int Mode					Best-Fi	t Mode		
plumb	ine - result	[3]				plumb	line - resuli	: [3]	
No.	Н	V	Distan.			No.	Н	V	Distan.
1	0	0	0			1	-0.072	-0.004	0
2	0	0	100			2	0.139	0.009	100
3	-0.434	-0.027	108			3	-0.067	-0.004	108
to	lerance	0.05				⁵ ⇔ To	blerance	0.05	
Re	ef. Points	1	2						
Be	ets fit	💒 Graph	1			R	ef.Points	Grap	h
Sa Sa	ave	7. Reme	asure			sa 🔛 Sa	ave	Reme	easure
R tole	Red indicate: erance is ex	s that ceeded	plumblin R C O P O	ne - result 단 전 정 정 •	1 2 3	2000 2000 2000 2000 3			
			I ol	erance	0.05		-		
			Re	r. Points		2			
			Bet	ts fit	Table	9			
			sav Sav	ve	7 Reme	easure	10		

56

8 Extended alignment tools

8.1 Flatness Program

8.1.1 Short explanation

The Flatness Program is applied to measure the flatness of different planes compared to a reference surface, which is formed by the laser beam. The measurement points of the plane can be arranged circular or rectangular with constant or variable bars. The plane can also include milling groves. Up to 1600 measurement points can be used as absolute values or calculated to a best-fit plane. Moreover, 3 points can be assembled to a reference plane.

Procedure: Plan the measurement and mark the points where the receiver shall be placed. Align the laser towards X- and Y- direction within 0,5 mm and start the Flatness Program. Use the S or M sensor as a receiver.

The receiver should be placed with its label facing upwards.

To start the Flatness Program, select "Flatness" which is a sub item of "Geometry" in the main menu and press **STREP**. The main screen of the program will appear. Main screen of the program

8.1.2 Main screen of the program

Functions in this window	Shortcuts in this window		
	1 Contii	nue work	
- Create a new grid (circular or triangular)	ABC Conti	nue measurement	
	3 DEF Open	file	
- Change parameters	4 4 Creat	e rectangular grid	
- Continue work	5 Creat	e circular grid	
	6 Chang	ge parameters	
- Luau saveu uala	Selec	t menu item	





8.1.3 Change parameters

To change the parameters, press for select the corresponding menu item and press

To define, which sensor shall be applied as the receiver, press $\frac{2}{ABC}$.

To select the measurement unit, press

To set a filter, press wxyz, enter a value for averaging and confirm with tree.

To get to the Auto-Router settings, press

Press^{ENTER} to save and leave the screen.

2. Sensor Used
⊙ Ѕ ○ М
5. Display Unit
💿 mm i 🔘 inch
0 9. Averaging <u>0. Setup autorouter</u>
~

8.1.3.1 Auto-Router

The Auto-Router can be deactivated or configured in the two following modes:

- From the left to the right (and vice versa)
- From the top to the bottom (and vice versa)

Press $1_{(1)}$ to turn it off.

To select the mode "left to right", press

To select the mode "top to bottom", press $\begin{bmatrix} 3 \\ DEF \end{bmatrix}$.

Press start, to confirm the selection and leave the screen.



8.1.4 Create or edit a rectangular grid

To create a new rectangular grid, press or select the according menu item and press with the amount of columns (from 2 to 40) and the amount of lines (from 2 to 40) in the beginning. Furthermore, you need to enter a value for the total width/length or line/column spacing. Every time, you change the total width/length, the values for the line/column spacing are recalculated (and vice versa). The grid is defined with constant line/column spacing. Single spacings can later on be changed independently from another.

Press **START**, to save and to get to the screen where you can edit the grid.



8.1.5 Create circular grid

To create a new circular grid, press in the corresponding menu item and press in the corresponding menu item and press in the analysis of the analysis of the amount of rings (from 2 to 10) and the amount of points

per ring (from 3 to 40). Press start, so save and to get to the screen where you can edit the grid.



8.1.6 Edit the grid

Use the arrow keys, to navigate through the grid.

	What should be noted in this window		Shortcuts in this window
	All required dimensions need to be entered	1	Change the line/ring position of the line/ring, which the selected point belongs to
	Functions in this window	2▲ ABC	Change the position of the column, which the selected point belongs to
		3 DEF	Add line/ring. Line is added on the bottom; ring is added as an outer ring
-	Change line position / radius of the ring	4 4 GHI	Delete line/ring, which the selected point belongs to
-	Change column position	5 JKL	Add column/point. Column is added on the right side; point
-	Add/delete line/ring		Clockwise Delete column, which the
-	Add/delete column/point	6 MNO	selected point belongs to
		8 & TUV	Save
		ENTER START	Go to measurement screen





Manual

8.1.9 Carry out measurement

Press in the grid screen, to get into the measurement screen. Use the arrow keys to select points. You can skip those points, where no values are necessary or where no measurements can be carried out.

	What should be noted in this window		Shortcuts in this window
	Wait until the data are ready before carrying out another measurement (sandglass symbol must not be blinking)		Delete selected point
	Functions in this window	F5	View result
-	Carry out measurement at the selected point	8 ≎ TUV	Save
-	Delete the selected point	*	Back to the grid screen
-	Replace measurement data at the selected point	ENTER START	Carry out measurement



8.1.10 View and save results

For a better understanding, the measurement results are displayed as a grid, where the relative position of the individual items is graphically displayed. Each point is displayed as a coloured circle or as a coloured triangle (triangle = reference point) and is equipped with "+", "-", or 0.

"+" indicates above and "-, indicates beneath the reference plane.

The **blue colour** indicates "excellent" (tolerance <25%)

The green colour indicates "good" (tolerance < 50%)

The yellow colour indicates "warning" (tolerance <100%)

The **red colour** indicates "bad" (tolerance < 50%)

The headline of the screen shows the coordinates and the measurement value of the selected point. The value depends on the selected mode.



8.1.11 Reference modes

There are three reference modes, you can select between by pressing

8.1.11.1 No reference plane

The result is an unchanged receiver value

8.1.11.2 Laser Plane

If no reference points are defined, the result is an unchanged receiver value, if three reference points are defined, the result is the difference between the calculated three-point-reference plane and the receiver value.

8.1.11.3 Best-Fit Plane

The result is the difference between the calculated Best-Fit-Plane and the receiver value.

PCE Instruments

Manual

No refe	rence plane	Las	ser Plane		Best-I	Fit Plane
[1;2]=0.16		[0;0]=0 (0,		[2;3]	=0.21	
667	m 介 1050	(⇒0	m 🏦 0	⇒1	000	m 2100
‡ 0	⊷ □ Ref. ✓ Enabled	‡ 0	₩ Ref. ✓ Enabled		74	Ref.
0123		0.123	· -		123	
	2			2^{1}		
-667 🛱	7	- UUUA		7	1000 + 0001	
	8		2	8		
	D *			D *		0

8.1.12 Define reference points

To define or delete reference points, use the arrow key. With the help of those, you can select a position and confirm with $\frac{7}{Pars}$. You can only define or delete reference points in the Laser Plane mode.

8.1.13 Result modes

There are three different modes to view the results.

Original: Values are shown as positive and negative values

All positive: Values are shown relative to the lowest value; values cannot be negative. All negative: Values are shown relative to the highest value; values cannot be positive.

Original		All posi	tive	All ne	gative
[2;3]=0.216 (•) ⇒ 1000 mn ‡ 0 ↔	2100 Ref. Enabled	aj=1.035 1000 m 0	2100 Ref. Enabled	2;3]=-0.873 ⇒ 1000 n r ‡ 0 ===================================	¥ 2100 Ref. Fnabled
			1 0 2 1 3 3 2 7 0 0 7 0 9 9 8 8 8 8 8 8 8 8		1 2 3 7 0 9 9 8 8 8 8

8.1.14 Enter tolerances

Press, to enter tolerances. Enter the required value to the entering field and confirm by pressing or press ^{F4}, to switch to the Auto Mode. If the Auto Mode is activated, the tolerances are defined as 35 % peak-to-peak.



8.1.15 View statistics

To view the statistics, press $\begin{bmatrix} 1 \\ \hline 0 \end{bmatrix}$

Maximum: maximum value Minimum: minimum value Peak-Peak: peak-to-peak value Average: average value Std.deviation: standard deviation value Tolerance: tolerance value

The coloured bar on the bottom of the screen shows error percentages and the amount of points in this error ranges. The coloured bar is defined as described in the following:

blue : value is $\leq 10\%$ of the tolerance **light blue:** value is between 10% and < 20% of the tolerance **green :** value is between 25% and < 0% of the tolerance **yellow:** value is between 50% and < 100% of the tolerance **red :** value is 100 % of the tolerance and more

Result-Statistic mm	×	
Maximum: Minimum: Peak-Peak: Average: Std. deviation:	1.089 -0.819 1.908 0 0.57	
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	50 100 2 2 1 25 10 %	2 points in the positive (over reference) red range
3D < Solution 3 points in negative (u reference) y range	the nder ellow	

8.2 Bores and centre line programme

8.2.1 Short explanation

This program is applied to measure the straightness of holes and drillings. For example, inner rings of ball bearings (also those with changing diameters) or stators of machines can be measured. Due to the multipoint function, measurements on up to 36 points in every angle for every bore are possible. Vertical objects can also be measured (manual angle entry must be activated). In the following, objects with bores to be measured are termed as plane.

Carry out bores centre line function

To start the program, select – "bores centre line" in the main menu under the sub item "Geometry" and press **STARP**. The main screen of the program will appear.

8.2.2 Main screen of the program (configuration of planes and changing of parameters)

	What should be noted in this window		Shortcuts in this window		
	The required dimensions should be entered correctly (can be changed later on, if recommended, measurement data will not be influenced).	0 DEL	Start a new measurement		
	Functions in this window		Enter amount of planes (holes)		
			Set or delete all distances equally		
		* =	Set current distance		
-	Create/change/view row of holes Set parameters	3 DEF	Enter hole diameter (optional). If only 3 measurement points are used, the entry of the hole diameter increases the accuracy of the measurement result		
-	Enter dimensions	5 JKL	Change parameters (manual data entry or of the sensor; manual angle entry or of the inclinometer; filter settings,)		
-	Start measurement	7 PQRS	View results (available, if all required measurements are finished)		
-	all required measurements are finished)	8 ¢ TUV	Save results to a file (see chapter 10 "Handling of the Data Dialogue window")		
-	Save		Load saved results from a file (see		
-	Load	9 ¢ WXYZ	chapter 10 "Handling of the Data Dialogue window")		
			Select hole, to enter the distance (to the next hole) and hole diameter.		



8.2.3 Configuration process

8.2.4 Carry out measurement

Press **START** in the main screen of the program and the measurement screen will appear.

What should be noted in this window	Sho	ortcuts in this window
Carry out a rough alignment of the laser, if you want to start a new measurement.	0 DEL	Delete the measurement points of the current plane (all saved values will be lost)
Functions in this window	1	Manual entry of the detector value
	4 ◀ GHI	Manual angle entry
- Carry out measurement	6 MNO	Switch measurement unit
 Manual data entry (if activated) Manual angle entry (if activated) 	F2	Open context menu
	8	Navigate forwards/backwards through the planes
		Navigate through measurement

8.2.5 Duration of the connection establishment

Depending on which interface is used to connect the sensors (Bluetooth or serial), the connection establishment can take between 2 and 30-40 seconds. It is recommended to wait about 10 seconds (cable connection) or about 50 seconds (wireless connection). If no connection is established after that time, check the sensors and the system settings of the PCE-TU 3.





Rough alignment of the laser beam Refer to **chapter 5.5 ("Rough alignment")**.

8.2.6 Carry out, view and replace measurements

To carry out a measurement, press

The saved measurement is now displayed in the measurement point screen. Please consider the following:

If the inclination indicator is yellow, the current inclination is not acceptable (the minimum rotation of about 10° could be fallen short of. If the manual angle entry is activated, a yellow inclination indicator means that the angle was not entered (in this case there is no pointer).

At least three measurements should be carried out to calculate the result. Save as many measurements as possible (max. 36) in order to receive a result as accurate as possible. The minimum rotation angle (amount of the particular rotations between the particular measurement points) cannot be under 170°. A red square on the top right of the measurement point indicator means, that the total angle is too low.



To view the saved measurements, use and . To replace a measurement, select the according measurement and press. A confirmation dialog will appear. Select "YES".

8.2.7 View and save results

If measurements have been carried out for all planes, press MENU for the result.

There are two reference models, you can switch between by pressing $\frac{5}{100}$

Ref Points Mode: If one of the reference points is undefined, the result is the unchanged detector value. If two reference points are defined, the result is the difference between the calculated reference line and the detector value.

To define reference points, press in and enter reference point number 1 and reference point number 2.

Press to save. In order to delete the reference points, enter the value

Best Fit Mode: In this mode, the result is the difference between the calculated best fit reference line and the detector value.

The result can be displayed as a graph or as a table. By pressing 2, you can switch between these illustrations.

To save the results, press **B ***. Refer to chapter 10 **"Handling of the Data Dialogue window"** to do that.



Press ^{MENU}, to return to the main screen of the program or press ^{STRP}, to start the Live Mode.
8.2.8 Live Mode

To carry out live alignment for the selected plane, place the detector in the centre of the bore. The clamping device should be fixed to the bottom side of the bore, inclined at 180°.

Switch from the reference line mode to the result mode and the table illustration. Select the required plane due to and ress and press to receive the measurement screen, where the Live Mode can be activated.



If the manual angle entry is activated, enter the corresponding value.

Press start again, to start the Live Mode.

Do not move any components until "LIVE MODE" appears on the screen.

Move the component towards zero with the help of the measurement values on the screen. To stop the Live Mode and to receive the result after the movement, press $\frac{7}{Pars}$.

Do not stop the Live Mode, if the measurement values are not ready (laser beam is out of aim, sand glass symbol or connection problems)





8.3 Straightness Program

8.3.1 Short explanation

The Straightness Program is applied to determine the straightness of objects. Very long objects can be measured in parts (Splices). The measurement of vertical objects is possible as well.

8.3.2 Carry out a straightness measurement

To start the program, select "Straightness" in the main menu under the sub item "Geometry" and press

8.3.3 Main screen of the program (configure positions and change parameters)

	What should be noted in this window		Shortcuts in this window	
	The required dimensions should be entered correctly (can be changed later on, if recommended, measurement data will not be influenced).	0 DEL	Start a new measurement	
	Functions in this screen	1	Enter number of measurement points (positions)	
		2▲ ABC	Equal or delete all distances	
-	Create/modify/view point	*	Enter current distance	
-	Create/modify/view Part (Splice)	3 DEF	Enter number of the parts (splices) – (optional). When using splices, this button adds a new part	
-	Change parameter		Change parameters (manual data entry	
-	Enter dimensions	5 JKL	or for the sensor; manual angle entry or for the inclinator; filter settings.	
-	Start measurement	7 PQRS	View results (available, if all required measurements have been carried out)	
-	View misalignment results (available, after all required measurements have been	8 \$ TUV	Save results to a file (see chapter 10 "Handling of the Data Dialogue window")	
-	Save	9¢ wxyz	Load saved results from a file (see chapter 10 "Handling of the Data Dialogue window")	
-	Load	8	Select point to enter distance	



8.3.4 Screen overview



8.3.5 Splice explanation

If a measured object is longer than the effective length of the laser system (10 m between the sensors), it can be divided into parts (splices) and measured that way. A part can consist of 3 up to 300 single measurement points where parts overlap in 2 up to 8 points (end of the previous part with the beginning of the current part). These overlaps are necessary to carry out a straightness measurement of the whole object correctly. If the effective length of the laser is longer than the measured object, there is no need to use parts (splices).

8.3.6 Configuration process

To enter the number of points, press 1 (i) and enter the desired value (3 up to 300 points are possible). Confirm the entry by pressing . Make sure, that all points are placed on the current part (splice). If the field "Splice no." displays "-", there is only one part.

If the distances between all points (in all splices) are the same, press and activate the "Equal Distances" checkbox. Press * now, to reach the field of distance entry, enter a value and confirm by pressing *. The entered value is used for all distances, if the checkbox "Equal Distances" is activated. If the distances between the points are not equal, use and , to select a point and press *, to enter the distance to the next point. Repeat the process for all points (except for the last one).

Note: If you use more splices, check the splice number displayed at "Splice no.", to check in which part you are currently situated. The distance between two overlap points cannot be edited.

To add a new splice, press 3_{DEF} and add "1" to the current "Splice no." (if the current value is "-", enter "2"). Configure the new splice after that.

If you want to change parameters, press 5, to reach the parameter screen. Here you can activate/deactivate the manual data entry by pressing 2 or the manual angle entry by pressing 3 pressing 5, Pressing 5, makes it possible to switch between the measurement units mm and inch. Press 6, to use the sensor S as your aim and press 7 pressing, if you want to use an external laser. For averaging, press

8.3.7 Carry out measurements

Press start in the main screen of the program, to get to the measurement screen.

What should be noted in this window	Sho	ortcuts in this window
Carry out rough alignment of the laser, when you start a new measurement	0 DEL	Delete measurement point
Functions in this window	1	Manual entry of detector value (V)
		Manual entry of detector value (H)
- Carry out measurement	6 MNO	Change measurement units
- Enter data manually (if activated)	F2	Open context menu
	0	Navigate forward/backward through the points

8.3.8 Duration of the connection establishment

Depending on which interface is used to connect the sensors (Bluetooth or serial), the connection establishment can take between 2 and 30-40 seconds. It is recommended to wait about 10 seconds (cable connection) or about 50 seconds (wireless connection). If no connection is established after that time, check the sensors and the system settings of the PCE-TU 3.



8.3.9 Rough alignment of the laser beam

Position the laser transmitter (sensor S is set by default) as close as possible at the beginning of the object (or at the first overlap point of the splice you want to measure, if more splices are used). Position the receiver (sensor M is set by default) as close as possible to the transmitter. Adjust the position of the transmitter, so that the laser beam maims the middle of the receiver. The laser position indicator on the display shows the exact position. Move the receiver as far as possible (but only on the particular splice) from the transmitter.

Adjust the position of the laser beam to the receiver with the help of the adjustment screws on the transmitter once again. The laser beam should aim the middle of the receiver again. Move the receiver to the first measurement point. Be sure that the right measurement point and the right splice (if used) are selected.

If the laser beam is out of the aim on the receiver, repeat the adjustment process. Rough alignment should be carried out once for each measurement object or each splice (if used).

Do not touch the transmitter or adjust the receiver in the course of the measurement.



To navigate through the saved values, use \bigcirc and \bigtriangledown . To replace the selected measurement value, press start and conform by pressing "Yes" in the following dialogue window.

8.3.11 View and save results

If the measurements for all planes are finished, press ^{MENU}, to view the result. There are two reference line models, you can switch between pressing ⁵

Ref.point Mode: if one of the reference points is undefined, the result is the unchanged receiver value. If two reference points are defined, the result is the difference between the calculated reference line and the receiver value.

To define reference points, press and enter reference point number 1 and reference point number 2. Press to confirm. In order to delete a reference point, enter as the value.

Best- Fit Mode: in this mode, the result is the difference between the calculated best fit reference line and the receiver value.

The result can be displayed as a table or a graph. Due to $\begin{bmatrix} 2 & a \\ ABC \end{bmatrix}$, you can switch between these illustrations.

To save the result, press, (refer to chapter 10,,Handling of the Data Dialogue window")

To return to the main menu of the program, press



Graph view

(keep in mind that the overlap points are not displayed in the graph. Therefore, the amount of measurement points is only 4 and not 6)





8.3.12 Tutorial for the use of splices

If you want to measure an object which is longer than the effective length of the laser measurement system, you need to divide it (only on paper) into individual sections (splices), which do not exceed the effective length (refer to the following picture). Keep in mind, that the minimal amount of measurement points should not be less than 3 and at least one more than the amount of overlap points (minimal amount of overlap points is 2). At the beginning, you need to carry out rough laser alignment for the first splice. If the measurements for the current splice are finished, move the transmitter as close to the overlap point as possible. Carry out rough laser alignment for the next splice and start the measurement. Place the receiver on the first overlap point. Check the display for the correct numbers of the point and the splice. The correlation of point number, splice and overlap point is shown in the following picture as well.

In this example, we divide the object into two splices. The first splice possesses 5 measurement points (positions) and the second splice possesses 6 measurement points including the overlap points. In the beginning, you need to collect the receiver values of the first slice (from Point 1 to Point 5). Move the transmitter to its next position (Yellow Square). Carry out rough laser alignment for the second splice.

Note:

Point 1 on the second splice has the same physical position on the object as Point 4 in the first splice. Point 2 on the second splice has the same physical position on the object as Point 5 in the first splice. The distance between Point 2 and Point 3 on the second splice is the distance between Point 5 on the first splice and Point 3 on the second splice so that this distance after the first splice contributes to the total length in the following.



8.3.13 Live Mode

Place the receiver on this position to carry out a live measurement on the selected position. Turn the result screen into the reference line mode and in the table view now. Select the required plane with

and resserver, to get to the measurement screen, where you can activate the live mode. Press another time, to start the live mode.

Do not move any objects, until a blinking "LIVE MODE" appears!

Move the object to the zero direction with the help of the measurement values on the screen. To stop the live mode and receive the result, press

Do not stop the Live Mode, while the measurement data are not ready (laser beam out of aim, sand glass symbol or connection problems)



Straightness - measure Pt.No:2 Spl:1 V: 0.087 H: 0.82 mm	After the Live Mode was stopped, another point can be selected. Select a new point, place the receive on the selected position, press and after that with the live Mode for the next selected plane. The alignment of a point can influence other points. Repeat the measurements after using the Live Mode (return to the result screen and press for the measurement)
RESULT [*] V: -0.214 H: 1.079	[*] indicates, that the point was aligned in Live Mode
Sto change plane Start' to take; 'MENU' to exit	

8.4 Rectangularity program ("Squareness programm")

This program is used to determine the rectangularity of two planes to each other. The rotatable laser transmitter RI-20 can emit laser beams in an exact angle of 90° with the help of its integrated Pentaprism. The two rectangular laser beams are used as a reference. Four measurements shall be carried out – two measurements on one plane and – after the direction of the laser beam was changed – two measurements on the other plane. Place the rotatable laser transmitter in the corner between both planes. Now you place the receiver (sensor M set by default) on the first position. Carry out rough alignment, if necessary.

8.4.1 Main screen of the program

	What should be noted in this window		Shortcuts in this window
	All required dimensions should be entered correctly (can be changed later on, if recommended)	0 DEL	Start new measurement or repeat measurement (all collected data will be lost)
_	Functions in this window Enter dimensions	*	Enter dimensions
-	Start measurement View results (available, if all required measurements are finished) Save	8 \$ TUV	Save all data in one file (see chapter 10 "Handling of the Data Dialogue window")
	Squareness		



8.4.2 Measurement process

Mark two points (near and far) on the first plane and repeat this action for the second plane. Press and enter the distance between Point 1 and Point 2. Confirm pressing and enter the distance between Point 3 and Point 4. Confirm again by pressing were. Place the rotatable laser transmitter in the corner between both planes and place the receiver on the first measurement point (far). Press now, to get to the measurement screen.



Having carried out the measurement for Point 1, move the receiver to Point 2 and carry out a measurement. Turn the rotatable laser transmitter 90° to the direction of the second plane afterwards. Carry out measurements for Point 3 and Point 4 now.

The RL-20 laser transmitter must not be moved after the beginning of the measurement. Be careful when you turn the laser beam.

The order of measurement data acquisition is not important for the measurement.



8.4.4 View and save results

To view the measurement results, press $\frac{7}{PORS}$. To save the results, press $\frac{8}{mv}$. To return to the main screen of the program, press $\frac{1}{mv}$. If you want to enter tolerances, press $\frac{6}{mv}$. If the calculated results are out of your tolerance range, the vertical plane is illustrated inclined and dark.



9 System settings

Functions in this window		Shortcuts in this window
- Set date and time		Set date and time
- Configure automatic turn-off		Configure automatic turn-off
- view/set up program licences		
 Set data transfer to the sensors (Bluetooth or serial) 	J DEF	View/set up program licences
 Retrieve firmware version and status information 	4 4 GHI	Set data transfer to the sensor
- Set language	5 V JKL	Set user language
	6	Cat UCD made
- Set USB-mode	MNO	Set OSB-mode



9.1 Set date and time

To set date and time, press 1

Functions in this window		Shortcuts in this window
		Navigate left between the fields
		Navigate right between the fields
		Increase the current value
		Decrease the current value
	*	Move between the fields (cyclically)
	MENU	Leave date and time settings (close
		window)
Day Month Dat. Time 5 / 11 10.01.2011 10.01.2011 10.01.2011 10.01.2011 10.05 Press 'MENU Build: 1.0.4436 S:S/N 10042400 Bat: 5.6 V [.05]	Year H P P P P P P P P P P P P P	Iour Minute Image: Selection of the selection of t



9.2 Configure automatic turn-off

To configure automatic turn-off, press

Functions in this window		Shortcuts in this window	
	Setting of the turn-off time in seconds	MENU	Leave without saving
	<i>Note 1:</i> To deactivate auto turn-off, set the time to zero or leave the box blank. <i>Note 2:</i> If the values below 30 seconds are entered, the box is highlighted in yellow in order to indicate a turn-off time which is to short.	ENTER	Confirm the new value



9.3 View/set up program licences

To view/set up program licences, press

Functions in this window		Shortcuts in this window	
 View licence status 			
 Add/update license by loading a license file (".lic") from the folder "My documents" or 	9 ¢ wxyz	Load license file (add/update license)	
from an SD card ("Storage Card" folder)			
- View serial number of the device	MENU	Exit	
- View unique ID of the device			

Program module icon and name	AVV-711 Setup License Manager c7229f97-9209-45f4	-801e-5bf733(X X 05c10f	Unique ID
	Module	Before	Valid	Valid license till this date (vear in 2 digit
	Horizontal.dll	01.01.99 01.01.99-	+	format, beginning from 2000, e.g. 99 = 2099)
	SoftFoot.dll	01.01.99	+	
	Flatness.dll Common.dll	01.01.99 01.01.99	+	Validity symbol "+" means valid "-" means
	Math711.dll	01.01.99	+	invalid or license not installed
	St. D.dli	01.01.99	**	
	24 1	20314000)1	Serial number

In order to get a license, send the serial number of the instrument to the salesman. If he sends you the license file, copy it to the "My documents" folder on your instrument or to the SD card and insert it.

To load this file, press and a loading dialog appears. Use the arrow keys to select the correct license file and press to load it. If you need to select another medium, press to get to the selection field. Use and to for the selection of the medium, the license file is located and press again, to get back to your file selection



9.4 Set data transfer of the sensor

To set the data transfer of the sensor, press

Functions in this window	Shortcuts in	this window
		Select Bluetooth interface
		Select serial interface
 Select between Bluetooth and serial interface Configure Bluetooth interface (Slave-Device-Number) 	If Bluetooth is activated	
		Use a sensor via Bluetooth
	2 ABC	Use both sensors via Bluetooth
	F2	(Not) Change the Bluetooth Slave Device – COD (does not change it)





9.5 Set the user language

To set the user language, press

Functions in this window	Shortcuts in this window	
		Navigate through available languages
Change user language		Save and exit
	MENU	Exit without saving





9.6 Set USB-mode

To set the USB-mode, press . To select the mass storage mode, press .

If you select the mass storage mode, the device can be used as a normal USB stick. If you select the Active Sync mode, you need the Microsoft Mobile Device Centre or Microsoft Active Sync 4.5 to get access to the device.

Do not start any loading or saving processes on the device, while the device is used via USB in mass storage mode.

Functions in this window	Shortcuts in this window	
		Select mass storage mode
 Change the USB mode between Active Sync and mass storage mode 		Select Active Sync Mode
		Save and exit
	MENU	Exit without saving

A Changes only become operative after restarting the device.



10 Handling of the Data Dialogue window

Explanation of the "Disk" selection field There are two different saving options

- -
- The "My documents" folder (internal, always available) The "Storage Card" folder (external SD card, only available, if an SD card is inserted) -

General structure of the Data Dialogue window

Current file path	🤛 SavetiMy Documents/Pdf 🛛 🚺	Folder and file list
	alg_H_autosave_4pt_pc.pdf	Folder and the list
	alg_H_autosave_bot_pc.pdf	
	6 sim_20110118024941.pdi	
Filename entering box (not available in the view mode)		Selection of the storage medium
	Risk: My Documents	Note bar
	File alg_H_autosave_4pt_pc.pdf	
	F2.Next F5.AutoName	



If folder and file list is sele Navigate through the list	cted:
Navigate through the list	
If the storage modium cal	action
field is selected:	ection
Select between internal s	orage
("My documents") and SE	card
("Storage Card")	
If folder and file list is sele	cted
CLR and you are at a subfolde	r:
- Select storage medium	folder
nierarchy lifelder and file liet is sele	ata di
- View files and folders	/filo
	nie
Navigate through folder hierarchy If folder and file list is sele	cted:
Create new folder	
Switch between folder and	d file
- Delete selected folder or file	tion
F3 field and the filename enter	ering
- Enter/edit filename	oction
F4 field is selected:	ection
- Generate filename automatically Open/hide dropdown mer	u
(current date + time) Generate filename autom	atically
(current date + time). The	name
appears automatically in t	he
corresponding entering fie	ld
If a folder is selected:	
Open folder / navigate do	wn one
	у
If a file is selected.	
Save file (overwrites the s	elected
file) or load data	

11 "My Documents" option

Functions in this window	Shortcuts in this window	
 Find/organize files and folders Save reports as a .pdf-file 	1	Find/organize folders and files, create new folders, delete folders and files
	2 ABC	Save the report as .pdf-file



11.1 Find/organize folders and files

To find/organize folders and files, press $1_{(1)}$.

Functions in this window	Shortcuts in this window	
	If the folder and file list is	
	Selected:	
	Navigate through the list	
- Find folders and files	If the storage medium selection field is selected:	
 Switch between internal storage and SD card 	Selection between SD card and	
	internal storage ("My	
- Delete folders	documents")	
Delata files	CLR Navigate a step up in the folder	
- Delete files	If the folder and file list is	
Orente e new felder	0 II the lolder and life list is	
- Create a new folder	selected: Delete folders of files	
	7 If the folder and file list is	
	selected: Create a new folder	
	F2 Switch between folder and file	
	list and the storage medium	
	selection field	





11.2 Save a report as PDF file

To save a report as .pdf-file, press

Functions in this window	Shortcuts in this window	
 Select report, which shall be save as .pdf-file. Select storage medium/folder/file, which shall be saved as a pdffile 	If the folder and file list is selected: Navigate through the list	
	If the storage medium is selected: Selection between SD card ("Storage Card") and internal storage ("My documents")	
	Move up a step within the folder hierarchy	
	0 DELIf the folder or file list is selected:Delete file or folder	
	7 PORSIf the folder or file list is selected: Create new folder	
	F2 F3 Switch between the folder and file list, the storage medium and the entry field for the file name	
	F4 If the storage medium is selected: Open/close the dropdown menu	
	F5Generate the file name automatically (current date + time)	
	Not recommended, use the original name instead.	
	If the folder or file list is selected: Move a step down in the folder	

Manual



hierarchy (open folder) Otherwise select a report in the view dialog and save the report in the save dialog.



12 Appendix

Standard tolerances for shaft alignment

In the following, you see the standard tolerances for the alignment of industrial machines with flexible coupling. Only use these tolerances, if there are no in-house guidelines or guidelines provided by the shaft manufacturer. Do not exceed these tolerances.

RPM	Good		Acceptable	
	Parallel	Angular	Parallel	Angular
	misalignment	misalignment	misalignment	misalignment
Up to 1000	0,08	0,07	0,12	0,10
Up to 2000	0,06	0,05	0,10	0,08
Up to 3000	0,04	0,04	0,07	0,07
Up to 4000	0,03	0,03	0,05	0,05
More than 4000	0,02	0,02	0,04	0,04

13 Disposal

For the disposal of batteries, the 2006/66/EC directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose.

In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company which disposes of the devices in line with law.

If you have any questions, please contact PCE Instruments.



14 Contact

If you have any questions about our range of products or measurement instruments please contact PCE Instruments.

14.1 PCE Instruments UK

By post: PCE Instruments UK Ltd. Units 12/13 Southpoint Business Park Ensign Way, Southampton Hampshire

United Kingdom, SO31 4RF

By phone:

02380 987 035

14.2 PCE Americas

By post: PCE Americas Inc. 711 Commerce Way Suite 8 Jupiter 33458 FL USA

By phone: 561 320 9162