







Specification

| Specification | |
|---------------------------|----------------------------------------------------------------|
| Model | SH-CH-800U |
| Type | Forced Convection Type |
| Dimension Internal | 1000×800×1000 (W×D×H) |
| Dimension External | 1200×1350×2150 |
| Capa | 150 L |
| Temp Accuracy & Stability | ±0.1℃ |
| Temp Uniformity | ±0.5℃ |
| Temp Range | -40°C to 150°C |
| Cool Down Time | 23°C ~ -40°C about 40min |
| Heating up Time | -40°C ~ 100°C about 40min |
| Temp Controller | Microprocess Prgrammable Controller Touch Screen Type |
| Time Range | 00.00 to 99HR 59MIN (MIN SEC) Selectable Digital Counter Timer |
| System | Air-Cooled |
| Gas | R-404A / R23 |
| Insulation | Poly-Urethan Foam |
| Power | 220V,1Ф(3Ф)or 380V ,3Ф |
| Material Internal | Stainless Steel SUS 304 with Polishing Finished |
| Material External | Steel Plate SS41 with Powder Heating Coated |
| Safety Device | Over Temp Protection Device |
| | Automatic reset function incoming power cut |
| | Buzzer On When Set Time Arrived |
| | Autodefrost System |
| Accessory | Stainless Steel Shelves 2EA |

Feature

Powerful Cool Down Function

Double Stage Refrigerator System has powerful cooling effect and it can reach extremely low temperature in a short time. Thus SH-CTC800SC is suitable for constant temp. test of exteremely low temperature.

Power saving Heating Up Function

SH-CTC800SC can adjust cooling ability of refrigerator when it goes up from low temp to high temp. Thus it can shorten the rising time up to high temp. Also it is very economic because it can decrease unnecesary power loss.

Non-dew condensation observation window installation

Thin film type heater is installed in non-dew condensation observation window which was done by 3 kinds of heat treatments. The window has no dew in







extremely low temerature test environment. Therefore temp distribution degree is excellent because the atmosphere flows well in chamber.

Powerful Interface function

SH-CTC800SC can send data and control the temperature of constant chamber by using RS-485 telecommunication between PC and Constant Chamber even though the distance between PC and Constant Chamber is far each other.

Supplying diverse operation display

With a simple display touch, SH-CTC800SC supplies diverse display mode such as Menu display, Operation display, Graphic display, Help Display. Thus it can prevent user's usual operation error.

Option